



VND 2-Pack

DJI Mavic Air 2S

What's Included

VND 2-PACK

Filters (2-5 & 6-9 stop) | Magnetic Case | Microfiber Cloth

Installation

Step 1

Install the filter before powering-on the drone.

Step 2

Support the gimbal in one hand. Using your other hand, push, and turn the stock UV counterclockwise and remove.

Step 3

Make sure your Air 2S lens is clean and clear of debris before filter installation.

Step 4

Support the gimbal in one hand. Using your other hand, place the filter tabs into their corresponding lens slots. When seated flush to the lens, turn clockwise until filter clicks into place.

Step 5

Rotate gold bezel to desired stop value. Verify the stop value aligns with the triangle located on the filter base.

More Info

Tutorials

For additional help be sure to visit our YouTube page:

[youtube.com/polarprofilters](https://www.youtube.com/polarprofilters)

for tutorials and more.

Questions

Contact us at anytime via our website, or shoot us an email. We're happy to help.

polarpro.com | 949.220.9395

support@polarpro.com