



# QUARTZLINE

*BlueMorphic, GoldMorphic, Mist / Mist-H*



---

# What's Included

**QLFX** ( *BlueMorphic, GoldMorphic, and Mist/Mist-H* )

*Filter | Defender 360 (Filter Cover, and Metal Cap)  
and Microfiber Cloth*

---

## Installation

Thread filter onto the front of your lens. Do not force it past the point of resistance. Please note the filters may be incompatible with some lens hoods.

### **Operation** (*BlueMorphic / GoldMorphic*)

Once installed, the bronze outer frame rotates allowing you to angle the flares.

---

## Defender360

1. With one hand, grip rubber sides of the Filter Cover on the rubber grips.
2. With your other hand, unthread the Protective Cap counterclockwise using the knurled sides.
3. Once the Protective Cap has been unthreaded from the filter, align the two tabs on the inside of the Protective Cap with the openings in the front of the Filter Cover.
4. Press the Protective Cap into the front of the Filter Cover and rotate clockwise 90 degrees.
5. The filter is now ready to be installed on the lens.

---

## More Info

### *Tutorials*

For additional help be sure to visit our YouTube page:

**[youtube.com/polarprofilers](https://www.youtube.com/polarprofilers)**

for tutorials and more.

### *Questions*

Contact us at anytime via our website, or shoot us an email. We're happy to help.

***polarpro.com*** | **949.220.9395**

***support@polarpro.com***