

What's Included

Kits, filters, and components.

Filmmaking Kit

CP Filter (includes hard-case + defender) | VND 3-5 Filter (includes hard-case + defender) | Phone Case | Grip

Directors Kit

CP Filter (includes hard-case + defender) | VND 3-5 Filter (includes hard-case + defender) | Mist VND 3-5 Filter (includes hard-case + defender) | Bluetooth Shutter | Phone Case | Grip

Filters

Filter | Hard-Case | Defender Lens Cover | Microfiber Cloth

Lenses

Lens | Protective Case | Filter Adapter Plate | Microfiber Cloth

Phone Case

Case | Wrist Tether

Bluetooth Shutter

Bluetooth Shutter Remote | Hex Tool | CR2032 Battery

Phone Grip

Grip

Filter Installation

Attaching filters to the case.



INSTALLATION

Step 1:

Place phone in the LiteChaser Pro 13 Pro/Pro Max case and turn off camera flash.

Step 2:

With the phone's camera side facing you, align prongs located on the filter with the receiver slots located on the case.

Step 3:

Insert filter prongs into the receiver slots until the filter is sitting flush with the case.

Step 4:

While gently pressing downward, slide filter to the right until it clicks into a secure position.

REMOVAL_

Step 1:

With the phone's camera side facing you, gently press filter to the left until the prongs release from case slots.

Lens Installation

Attaching lenses to the case.



Note, anamorphic lenses require the use of third-party apps (such as Filmic Pro) to de-squeeze footage in post.

INSTALLATION

Step 1:

Place phone in the LiteChaser Pro 13 Pro/Pro Max case.

Step 2:

With the camera side of the phone facing you, locate the wider prong on the back of the lens and align with the corresponding wider opening on the case above the desired lens (1x Wide or 2x Telephoto).

Step 3:

Insert the lens prongs into the receiver slots until the lens base is sitting flush with the case.

Step 4:

Rotate the lens 90-degrees to reach the 1st locked position where you will feel a click. If using an anamorphic lens, and you wish to change shooting orientation, rotate the lens another 90-degrees until you feel it reach a hard stop.

REMOVAL

Step 1:

Rotate lens to counter clockwise until it reaches a hard stop, then pull the lens out.

FILTER ADAPTER PLATE

Step 1:

Press the adapter plate onto lens (pressure-fit design). Filters install the same way as they do on the case.

Grip Installation

Attaching the grip to the case



INSTALLATION

Step 1:

Place phone in the LiteChaser Pro 13 Pro/Pro Max case.

Step 2:

Choose desired mounting side (front or back of the case).

Step 3:

Using your thumb, slide the gold switch upwards, then push down to release locking ends of the grip.

Step 4:

Place the grip around the phone case, aligning the ends with one of the four predetermined rail system grooves located on the side of the case and release the grip switch.

Step 5:

Ensure the locking ends of the grip are secure by squeezing the ends of the grip. Make sure the grip is level and tight against the case and double check the red indicator isn't showing on the grip switch before use.

REMOVAL

Step 1:

To remove, repeat step 3 and detach.

Bluetooth Shutter Installation

Attaching the bluetooth shutter to the grip.



INSTALLATION

Step 1:

Flip open the rubber weather-proof flap located at the top of the Bluetooth Shutter to access hex bolt.

Step 2:

Align the hex bolt with the 1/4"-20 thread on the grip and tighten down securely into position.

REMOVAL

Step 1:

To remove, reverse steps 1 and 2 listed above.

OPERATION_

Step 1:

Switch the toggle on the Bluetooth Shutter from the "off" position to "on" position. A green light will illuminate when "on".

Step 2:

To connect, locate the Bluetooth settings on your mobile device. Connect to LCP-BT-SHUTTER.

Step 3:

Once connected, the light on the Bluetooth Shutter will flash for photo and video when pressed/engaged.

More Info

Questions and support.

QUESTIONS?

Reach out any time via live-chat on our website, or shoot us an email. We're happy to help!

polarpro.com | support@polarpro.com | 949.220.9395